

ENGINE FUEL & EMISSION CONTROL SYSTEM

SECTION **EF & EC**

EF & EC

CONTENTS

PRECAUTIONS	EF & EC- 3
ENGINE AND EMISSION CONTROL PARTS LOCATION	EF & EC- 4
E C C S. DIAGRAM	EF & EC- 5
E C C S CHART	EF & EC- 7
FUEL FLOW SYSTEM DESCRIPTION	EF & EC- 9
AIR FLOW SYSTEM DESCRIPTION	EF & EC- 10
E.C.C.S. CIRCUIT DIAGRAM	EF & EC- 11
E.C.C.S WIRING DIAGRAM	EF & EC- 12
E C C S DESCRIPTION	EF & EC- 14
DIAGNOSTIC PROCEDURE	EF & EC- 31
SELF-DIAGNOSIS	EF & EC- 36
ELECTRONIC CONTROL SYSTEM INSPECTION	EF & EC- 52
CRANK ANGLE SENSOR	EF & EC- 54
AIR FLOW METER	EF & EC- 56
CYLINDER HEAD TEMPERATURE SENSOR	EF & EC- 58
IGNITION SIGNAL	EF & EC- 60
FUEL PUMP	EF & EC- 62
DETONATION SENSOR	EF & EC- 64
FUEL TEMPERATURE SENSOR	EF & EC- 66
START SIGNAL	EF & EC- 68
THROTTLE VALVE SWITCH	EF & EC- 70
VEHICLE SPEED SENSOR	EF & EC- 72
EXHAUST GAS SENSOR	EF & EC- 74
INJECTOR	EF & EC- 76
POWER SOURCE & GROUND CIRCUIT FOR E C U	EF & EC- 78
A I V CONTROL SOLENOID VALVE	EF & EC- 80
E G R CONTROL SOLENOID VALVE	EF & EC- 82
IDLE-UP SOLENOID VALVE	EF & EC- 84
A A.C. VALVE	EF & EC- 86

PRECAUTIONS

BATTERY

- Always use a 12 volt battery as power source
- Do not attempt to disconnect battery cables while engine is running

INJECTOR

- Do not disconnect injector harness connectors with engine running
- Do not apply battery power directly to injectors

E C C S PARTS HANDLING


- Handle air flow meter carefully to avoid damage
- Do not disassemble air flow meter
- Do not clean air flow meter with any type of detergent
- Do not disassemble auxiliary air control valve (VG30ET engine)
- Even a slight leak in the air intake system can cause serious problems
- Do not shock or jar the crank angle sensor

E.C.U

- Do not disassemble E C C S control unit
- Do not turn diagnosis mode selector forcibly
- Do not disassemble the E C U (the E C C S control unit)
- If a battery terminal is disconnected, the memory will return to the ROM value. The E C C S will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.

WIRELESS EQUIPMENT

- When installing C B ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on its installation location
- 1) Keep the antenna as far as possible away from the electronic control units
 - 2) Keep the antenna feeder line more than 20 cm (7.9 in) away from the harness of electronic controls. Do not let them run parallel for a long distance
 - 3) Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller
 - 4) Be sure to ground the radio to vehicle body



FUEL PUMP

- Do not operate fuel pump when there is no fuel in lines
- Do not reuse fuel hose clamps
- Tighten fuel hose clamps to the specified torque


E C C S PARTS HANDLING

- Securely connect E C C S harness connectors. A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs
- Keep E C C S harness at least 10 cm (3.9 in) away from adjacent harnesses, to prevent an E C C S system malfunction due to receiving external noise, degraded operation of ICs, etc
- Keep E C C S parts and harnesses dry
- Before removing parts, turn off ignition switch and then disconnect battery ground cable

WHEN STARTING

- Do not depress accelerator pedal when starting
- Immediately after starting, do not rev up engine unnecessarily
- Do not rev up engine just prior to shutdown


ENGINE AND EMISSION CONTROL PARTS LOCATION



SEF182F

E.C.C.S. DIAGRAM


VG30E Engine (Without turbocharger)



SEF183F


E.C.C.S. CHART

VG30E Engine (Without turbocharger)




E.C.C.S. CHART

VG30ET Engine (With turbocharger)




FUEL FLOW SYSTEM DESCRIPTION

VG30E engine (Without turbocharger)





SEF283F

VG30ET engine (With turbocharger)




SEF284F

AIR FLOW SYSTEM DESCRIPTION




E.C.C.S. CIRCUIT DIAGRAM




SEF180F


E.C.C.S. WIRING DIAGRAM



E.C.C.S. WIRING DIAGRAM




E.C.C.S. DESCRIPTION



Components

E.C.U. (E.C.C.S. control unit)


The E.C.U. consists of a microcomputer, inspection lamps, a diagnostic mode selector, and connectors for signal input and output, and for power supply. The unit has control of the engine.




CRANK ANGLE SENSOR

The crank angle sensor is a basic component of the entire E.C.C.S. It monitors engine speed and piston position, and sends to the E.C.U. signals on which the controls of fuel injection, ignition timing and other functions are based.

The crank angle sensor has a rotor plate and a wave forming circuit. The rotor plate has 360 slits for 1° signal (crank angle signal) and 6 slits for 120° signal (engine speed signal). Light Emitting Diodes (LED) and Photo Diodes are built in the wave forming circuit.



When the rotor plate passes the space between the LED and the Photo Diode, the slits of the rotor plate continually cut the light which is sent to the photo diode from the LED. This causes generating rough-shaped pulses. They are then converted into on-off pulses by the wave forming circuit, which are sent to the E.C.U.




AIR FLOW METER

The air flow meter measures the mass flow rate of intake air. Measurements are made in such a manner that the control circuit emits an electrical output signal in relation to the amount of heat dissipated from the hot wire placed in the stream of intake air.

The air flowing around the hot wire removes the heat from the hot wire. The temperature of the hot wire is very sensitive to the mass flow rate of the air. The higher the temperature of the hot wire, the higher its resistance value. This change in the temperature (or resistance) is determined by the mass flow rate of the air. The control circuit accurately regulates current (I) in relation to the varying resistance value (R_H) so that V_A always equals V_B . The air flow meter transmits an output for voltage V_A to the control unit where the output is converted into an intake air signal.

Also, this air flow meter has self-burning off system in order to make hot wire clean.




E.C.C.S. DESCRIPTION

Components (Cont'd)

CYLINDER HEAD TEMPERATURE SENSOR

The cylinder head temperature sensor, built into the cylinder head, monitors changes in cylinder head temperature and transmits a signal to the E C U


The temperature sensing unit employs a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise



THROTTLE VALVE SWITCH


The throttle valve switch is attached to the throttle chamber and actuates in response to accelerator pedal movement

This switch has idle contact and full throttle contact. The idle contact is used for engine control. It closes when the throttle valve is positioned at idle, and opens when it is at any other position.



FUEL INJECTOR


The fuel injector is a small, precision solenoid valve. As the E C U outputs an injection signal to each fuel injector, the coil built into the injector pulls the needle valve back, and fuel is injected through the nozzle to intake manifold. The amount of fuel injected is controlled by the E.C.U. as an injection pulse duration.



FUEL TEMPERATURE SENSOR


The fuel temperature sensor is built into the pressure regulator, and senses fuel temperature. When the fuel temperature is higher than the specified level, the E C U enriches fuel injected.

Do not remove fuel temperature sensor from pressure regulator. Always replace as an assembly.



FUEL PUMP

The fuel pump with a fuel damper is an in-tank type, that is the pump and damper are located in the fuel tank. The vane rollers are directly coupled to a motor which is cooled by fuel.




E.C.C.S. DESCRIPTION

Components (Cont'd)


IDLE-UP SOLENOID VALVE [VG30E]

The idle-up solenoid valve is attached to the intake collector. The solenoid valve actuates to stabilize idle speed when engine load is heavy because of electric load, power steering oil pump, etc.



A.A.C. (AUXILIARY AIR CONTROL) VALVE [VG30ET]


The A.A.C. valve is attached to the intake collector. The E.C.U. actuates the A.A.C. valve by an ON/OFF pulse of approximately 160 Hz. The longer that ON duty is left on, the larger the amount of air that will flow through the A.A.C. valve.



DETONATION SENSOR [VG30ET]

The detonation sensor is attached to the cylinder block and senses engine knocking conditions.


A knocking vibration from the cylinder block is applied as pressure to the piezoelectric element. This vibrational pressure is then converted into a voltage signal which is delivered as output.



AIR REGULATOR


The air regulator provides an air by-pass when the engine is cold for the purpose of a fast idle during warm-up.

A bimetal, heater and rotary shutter are built into the air regulator. When the bimetal temperature is low, the air by-pass port is open. As the engine starts and electric current flows through a heater, the bimetal begins to rotate the shutter to close off the by-pass port. The air passage remains closed until the engine is stopped and the bimetal temperature drops.



A.I.V. (AIR INJECTION VALVE)

The air injection valve sends secondary air to the exhaust manifold, utilizing a vacuum caused by exhaust pulsation in the exhaust manifold. When the exhaust pressure is below atmospheric pressure (negative pressure), secondary air is sent to the exhaust manifold. When the exhaust pressure is above atmospheric pressure, the reed valves prevent secondary air from being sent back to the air cleaner.



E.C.C.S. DESCRIPTION





Components (Cont'd)

EXHAUST GAS SENSOR (Titania type) [VG30ET]


The exhaust gas sensor, which is placed in the exhaust tube, monitors the amount of oxygen in the exhaust gas

This sensor is made of ceramic titania which electric resistance drastically changes at the ideal air-fuel ratio

The E C U supplies the sensor with approximately 1V and takes an output voltage of the sensor depending on its resistance. In order to activate the sensor element, it is equipped with a heater




SEF285D



EXHAUST GAS SENSOR (Zirconia type) [VG30E]

The exhaust gas sensor, which is placed into the exhaust manifold, monitors the amount of oxygen in the exhaust gas


The sensor has a closed-end tube made of ceramic zirconia. The outer surface of the tube is exposed to exhaust gas, and the inner surface to atmosphere. The zirconia of the tube compares the oxygen density of exhaust gas with that of atmosphere, and generates electricity. In order to improve generating power of the zirconia, its tube is coated with platinum. The voltage is approximately 1V in a richer condition of the mixture ratio than the ideal air-fuel ratio, while approximately 0V in leaner conditions. The radical change from 1V to 0V occurs at around the ideal mixture ratio. In this way, the exhaust gas sensor detects the amount of oxygen in the exhaust gas and sends the signal of approximately 1V or 0V to the E C U.



SEF288D

POWER TRANSISTOR AND IGNITION COIL

The ignition signal from the E C U is amplified by the power transistor, which turns the ignition coil primary circuit on and off, inducing the proper high voltage in the secondary circuit.



E.C.C.S. DESCRIPTION



Components (Cont'd)

VEHICLE SPEED SENSOR

The vehicle speed sensor provides a vehicle speed signal to the E.C.U.


- **Needle type speedometer models**

The speed sensor consists of a reed switch, which is installed in the speed meter unit and transforms vehicle speed into a pulse signal.




- **Digital type speedometer models**

The speed sensor consists of an L.E.D., photo diode, shutter and wave forming circuit. Its principle is the same as that of the crank angle sensor



A.I.V. CONTROL SOLENOID VALVE (TYPE B)

The A.I.V. control solenoid valve cuts intake manifold vacuum signal for A.I.V. control. The solenoid valve actuates in response to the ON/OFF signal from the E.C.U. When the solenoid is off, the vacuum signal from the intake manifold is cut. As the control unit outputs an ON signal, the coil pulls the plunger downward, and feeds the vacuum signal to the A.I.V. control valve.




E.G.R. CONTROL SOLENOID VALVE (TYPE A)

The E.G.R. system is controlled only by the E.C.U. At both low and high speed revolution of engine, the solenoid valve turns on and accordingly the E.G.R. valve cuts the exhaust gas leading to the intake manifold.

P.R. (PRESSURE REGULATOR) CONTROL SOLENOID VALVE (VG30E: TYPE A, VG30ET: TYPE B)

The solenoid valve actuates in response to the ON/OFF signal from the E.C.U. When it is off, a vacuum signal from the intake manifold is fed into the pressure regulator. As the control unit outputs an ON signal, the coil pulls the plunger downward, and cuts the vacuum signal.





SAFETY RELAY

Safety relay, which is located behind the right side of hood/ledge, prevents any damage to the E.C.U. and injectors when battery terminals are connected in reverse.

E.C.C.S. DESCRIPTION

Fuel Injection Control



The E.C.U. calculates the basic injection pulse width by processing signals from crank angle sensor and air flow meter. Receiving signals from each sensor which detects various engine conditions, the E.C.U. adds various enrichments, which are pre-programmed in the control unit, to the basic injection amount. Thus, the optimum amount of fuel is injected through the injectors.


1) Fuel enrichment

In each of the following conditions, fuel is enriched.

- During warm-up
- When starting
- After idle
- With heavy load
- When cylinder head temperature is high.

The enrichment rate for "when accelerating" and "with heavy load" are pre-programmed for engine speed and basic injection pulse width.

E.C.C.S. DESCRIPTION




Fuel Injection Control (Cont'd)

2) Mixture ratio feedback control

The mixture ratio feedback system is designed to control the mixture ratio precisely to the stoichiometric point so that the three-way catalyst can minimize CO, HC and NOx emissions simultaneously. This system uses an exhaust gas sensor located in the exhaust manifold to give an indication of whether the air-fuel ratio is richer or leaner than the stoichiometric point. The control unit adjusts the injection pulse width according to the sensor voltage so the mixture ratio will be within the narrow window around the stoichiometric air fuel ratio.

However, this system will open under the following conditions:

- When starting
- When engine and exhaust gas sensor is cold.
- When driving at high speeds or under heavy load.
- At idle
- When exhaust gas sensor monitors a too lean condition for more than 10 seconds.
- When fuel shut-off is in operation
- When exhaust gas sensor is malfunctioning
- When pressure regulator control system is in operation



3) Injection timing

Two types of fuel injection systems are used – simultaneous injection and group injection. In the former, fuel is injected into all six cylinders simultaneously twice each engine cycle.


In other words, pulse signals of the same width are simultaneously transmitted from the E.C.U to the six injectors two times for each engine cycle.

In the group injection system, six injectors are divided into two groups – No 1, No 2, No 3 and No 4, No 5, No 6. And fuel is injected into each group separately once each engine cycle.

When any of the following conditions are met, fuel injection shifts to simultaneous injection from group injection

- Engine speed is more than 3,000 rpm
- Cylinder head temperature is below 60°C (140°F).
- When starting

E.C.C.S. DESCRIPTION



Ignition timing is controlled, corresponding to the engine operating conditions, by the E.C.U. that is, as the optimum ignition timing in each driving condition has been pre-programmed in the control unit, the ignition timing is determined by electrical signals processed in the unit

The signal from the E.C.U. is transmitted to power transistor, and controls ignition timing


Detonation feedback operation

The retard system by detonation sensor is designed only for emergencies on VG30ET engines. The basic ignition timing is pre-programmed within the anti-knocking zone, even if recommended fuel is used under dry conditions. Consequently, the retard system does not operate under normal driving conditions.

However, if engine knocking occurs, the detonation sensor monitors the knocking condition and the signal is transmitted to the E.C.U. After receiving it, the control unit retards the ignition timing to avoid the knocking condition.

E.C.C.S. DESCRIPTION

Idle-up Control (VG30E engine)



The idle speed is compensated by the E.C.U to prevent rough idle when any of the following conditions are met.



The control unit senses the idle condition, and determines ON/OFF signal. The signal from the control unit is transmitted to the idle-up solenoid valve to stabilize idle speed.

Operation

Condition	Idle-up solenoid operation
During engine start 20 seconds after engine start Battery voltage is below 12V Headlamp switch ON Cooling fan switch ON Power steering oil pressure switch ON	ON
Except above	OFF

E.C.C.S. DESCRIPTION

Exhaust Gas Recirculation (E.G.R.) Control



SEF642B

OPERATION

In the exhaust gas recirculation system, some of the exhaust gas is returned to the combustion chamber to lower the flame temperature during combustion. This results in a reduction of the nitrogen oxide density in the exhaust gas.



When the E.G.R. control valve is open, some of the exhaust gas is led from the exhaust manifold to the E.G.R. tube. The exhaust gas is then regulated by E.G.R. valve, and is introduced into the intake manifold.

The signal from the E.C.U. is sent to the E.G.R. control solenoid valve, which cuts the vacuum line for the E.G.R. control valve when any of the following conditions are met:

Condition	E G R control solenoid	E G R system
Engine starting Throttle valve switch "ON"		
Under heavy load driving Low engine temperature High engine temperature Engine speed above 2,700 rpm	ON	Does not operate
Except above	OFF	Operates

E.C.C.S. DESCRIPTION

Fuel Pump Control



2) Fuel pump relay ON-OFF control (terminal 20)

Condition	Fuel pump relay operation	Fuel pump operation
Ignition switch is turned to ON	ON for 5 seconds	Operates for 5 seconds
When engine is starting [Engine temp above 100°C (212°F)]	ON	Operates
After started [Engine temp above 100°C (212°F)]	ON for 30 seconds	Operates
When engine stalls and except as shown above	OFF	Stops

Description

The fuel pump is controlled by the E.C.U adjusting the output voltage supplied to the fuel pump

Fuel pump ON-OFF control

1) Fuel pump ON-OFF control (terminal 108)


Condition	Fuel pump operation
Ignition switch is turned to ON	Operates for 5 seconds
Engine running and cranking	Operates
When engine is stopped	Stops in 1 second
Except as shown above	Stops

Fuel pump voltage control

Conditions	Voltage
5 seconds after ignition switch is turned to ON	Approximately 13.4 [V]
Engine cranking	
30 seconds after engine start [above 50°C (122°F)]	
Engine temp above 90°C (194°F) [Idle switch "OFF"]	
Engine temp below 10°C (50°F)	
Except above	9.4 ~ 13.4 [V]

E.C.C.S. DESCRIPTION

Air Injection Valve (A.I.V.) Control



The exhaust air induction system is designed to send secondary air to the exhaust manifold, utilizing a vacuum caused by exhaust pulsation in the exhaust manifold.

The exhaust pressure in the exhaust manifold usually pulsates in response to the opening and closing of the exhaust valve and it decreases below atmospheric pressure periodically.

If a secondary air intake pipe is opened to the atmosphere under vacuum conditions, secondary air can be drawn into the exhaust manifold in proportion to the vacuum.


The air injection valve is controlled by the E.C.U., corresponding to the engine temperature. When the engine is cold, the A.I.V. control system operates to activate the 3-way catalytic converter quickly. This system also operates during deceleration for the purpose of blowing off water around the air injection valve.

Condition	A I V control solenoid	A I V control system
Low engine temp	ON	Operates
During deceleration		
Except above*	OFF	Does not operate

* Including cylinder head temperature sensor circuit malfunctioning

E.C.C.S. DESCRIPTION


Pressure Regulator Control



This system improves the startability in hot condition by cutting off the intake manifold vacuum and increasing the fuel pressure.


For VG30ET engine, the fuel line is imparted with high pressure which has been stored in the surge tank while the engine was running with turbocharger.

Operation



E.C.C.S. DESCRIPTION

Air Regulator Control




Description

The air regulator is controlled by the E.C.U at the same time as fuel pump ON-OFF control

Operation (Air regulator ON-OFF control)

Condition	Air regulator operation
Ignition switch is turned to ON	Operates for 5 seconds
While engine is running and cranking	Operates
When engine is stopped	OFF in 1 second
Except as shown above	OFF

Exhaust Gas Sensor Heater Control





The E.C.U. controls the heater operation in the following way.

Operation

Condition	Exhaust gas sensor heater
<ul style="list-style-type: none"> Engine speed is less than 2,800 rpm (VG30ET) 3,200 rpm (VG30E) Except under heavy load 	ON
Except as shown above	OFF

E.C.C.S. DESCRIPTION

Air Flow Meter Self-cleaning Control



Description

After the engine is stopped, the E.C.U. heats up the hot wire to approximately 1,000°C (1,832°F) to burn out dust which adhered to the hot wire.

Operation

Condition	Self-cleaning system
<ul style="list-style-type: none"> • Engine speed has not exceeded 1,500 rpm before key off • Vehicle speed has not exceeded 20 km/h (12 MPH) before key off • Cylinder head temperature is higher than 115°C (239°F) when key off • Engine stall with key in ON position 	Does not operate
Except as shown above	Operates

E.C.C.S. DESCRIPTION

Fail-safe System

AIR FLOW METER

Description

When the output voltage of air flow meter is lower than the preprogrammed value, the E.C.U. judges it as a malfunctioning of air flow meter. The E.C.U. fixes the systems in the following condition.

Operation

System	Fixed condition
E G R control system	OFF
Idle speed control system	A duty ratio is fixed at the preprogrammed value
Fuel injection control system	Fuel is shut off above 2,000 rpm (Engine speed does not exceed 2,000 rpm)

CYLINDER HEAD TEMPERATURE SENSOR

Description


When the output signal of cylinder head temperature sensor is abnormal the E.C.U. judges it as a malfunctioning of cylinder head temperature sensor.

The E.C.U. decides the cylinder head temperature according to the time from ignition switch ON.

Operation

Condition	Cylinder head temperature decided
Just as ignition switch is turned ON or Start	20° C (68° F)
More than 6 minutes after ignition ON or Start	80° C (176° F)
Except as shown above	20 - 80° C (68 - 176° F) (Depends on the time)

DIAGNOSTIC PROCEDURE



Driveability

1. Make sure that the following items are in proper condition
CHECK DATA.

1) Idle speed

VG30E (M/T & A/T in "D" position):

700±50 rpm at sea level

650±50 rpm at high altitudes

VG30ET:

M/T

700±50 rpm

A/T

650±50 rpm (in "D" position)

2) Ignition timing

VG30E:

20°±2° B.T.D.C.

VG30ET:

15°±2° B.T.D.C.

3) Idle CO

○ 0.2 - 4.0% (in tail pipe)

- Throttle valve switch harness connector disconnected (No A.I.V. controlled condition)
- Cylinder head temperature sensor harness connector disconnected and then 2.5 kΩ resistor connected.
- Exhaust gas sensor harness connector disconnected.

○ Flashes of E.C.U. red inspection lamp in mode II (If flashes, O.K.)

4) Mixture ratio at approximately 2,000 rpm of engine speed.
Number of flashes of E.C.U. inspection green lamp in mode I'

5 times or more/10 seconds


5) Engine speed of idle switch OFF → ON

M/T: Idle speed + 250±150 rpm

**A/T: Engine speed (In "N" position)
+ 250±150 rpm**

If N.G., adjust to the specified value.

See page EF & EC-99.



2. Perform driving test



Evaluate effectiveness of adjustments by driving vehicle

During driving vehicle, perform real time diagnostic test

DIAGNOSTIC PROCEDURE

Driveability (Cont'd)

3. Perform E C C S self-diagnosis
See page EF & EC-36.




4. If the result of driveability test is unsatisfactory, or malfunctioning conditions are found in performing E C C S self-diagnosis and real time diagnostic test, perform general inspection, electronic system inspection and real time diagnostic inspection by following DIAGNOSTIC TABLES 1 and 2 in response to driveability trouble items. If N G, repair or replace.

See page EF & EC-33.

5. Perform switches ON/OFF diagnostic test.

See page EF & EC-44.



6. Perform driving test.

Re-evaluate vehicle performance after all inspections.

DIAGNOSTIC PROCEDURE

Diagnostic Table 1

SYSTEM INSPECTION TABLE

System	Sensor & actuator	Crank angle sensor	Air flow meter	Cylinder head temperature sensor	Ignition switch	Injector	Throttle valve switch	Neutral switch	Exhaust gas sensor
	Reference pages for inspection	EF & EC-54	EF & EC-56	EF & EC-58	Refer to EL section	EF & EC-76	EF & EC-70	EF & EC-88	EF & EC-74
Fuel injection & mixture ratio feedback control		○	○	○	○	○	○	○	○
Ignition timing control		○	○	○	○		○		
Idle speed control		○		○	○		○	○	
EGR control		○		○	○		○		
AIV control				○	○		○		
Fuel pump control		○		○	○		○		
Fuel pressure control					○				
Air regulator control		○			○				
Air flow meter self-cleaning control		○		○	○				

System	Sensor & actuator	Battery voltage	AIV control solenoid valve	EGR control solenoid valve	Idle-up solenoid/AAC valve	Fuel temperature sensor	Vehicle speed sensor	Air regulator	PR control solenoid valve
	Reference pages for inspection	-	EF & EC-80	EF & EC-82	EF & EC-84/86	EF & EC-66	EF & EC-72	EF & EC-92	EF & EC-90
Fuel injection & mixture ratio feedback control		○				○	○		
Ignition timing control	Power transistor						○		
Idle speed control		○			○*		○		
EGR control				○					
AIV control			○						
Fuel pump control	Fuel pump relay								
Fuel pressure control						○			○
Air regulator control								○	
Air flow meter self-cleaning control							○		

* Input switch

- ① Power steering oil pressure switch
- ② Heater or Air conditioner switch
- ③ Lighting switch & rear defogger switch
- ④ Radiator fan switch

This table indicates the inspection items for the E C C S. control system. For each system, it is necessary to check sensors or actuators marked "○".

DIAGNOSTIC PROCEDURE

Diagnostic Table 2

DRIVEABILITY INSPECTION TABLE

INSPECTION ITEM	GENERAL INSPECTION												E C S S SYSTEM INSPECTION												
	FUEL FLOW SYSTEM				ELECTRIC SYSTEM				AIR FLOW SYSTEM				IDLE UP SOLENOID VALVE		CRANK ANGLE SENSOR		AIR FLOW METER		CYLINDER HEAD TEMPERATURE SENSOR						
	Fuel level	Fuel pump	Fuel filter	Fuel line	Battery	Spark plug	Ignition wire	Alternator	Starter	Air cleaner	Air flow line	EGR valve	F I C D solenoid valve	Air regulator	P C V	Short	Open	120° signal noise	120° signal faults	1° signal faults	Poor connection	Short	Open	Poor connection	
TROUBLE ITEMS CONCERNED WITH DRIVEABILITY	-	-	-	-	-	-	-	Refer to EL section	-	-	-	-	EF & EC 112	EF & EC 93	-	-	-	EF & EC 54	EF & EC 56	EF & EC 58	-	-	-	-	
						⊗																			
						⊗																			
SURGE	Heavy load																								
	ROAD/LOAD DRIVING																								
	Middle load																								
ACCELERATION	Light load																								
	ACCELERATION DRIVING																								
	Slow acceleration																								
DECELERATION	Rapid deceleration																								
	DECELERATION DRIVING																								
	Slow deceleration																								
HESITATION	Rapid acceleration																								
	HESITATION																								
	Slow acceleration																								
STUMBLE	Rapid acceleration																								
	STUMBLE																								
	Slow acceleration																								
BACKFIRE	Backfire																								
	BACKFIRE																								
	After fire																								
IDLE STABILITY	Idle stability																								
	IDLE STABILITY																								
	Engine stall																								
STARTABILITY	Startability																								
	STARTABILITY																								
	Startability																								


This table indicates the inspection items for each type of symptom. It is necessary for each symptom to check sensors or actuators marked "⊗" or "⊙". Items marked "⊗" have a significant influence on driveability. Prior to items marked "⊙", check items marked "⊗". Improper mixture ratio, improper ignition condition, and an excess of EGR volume can cause any symptom. * If injector or air flow meter circuit is short or open, the fail safe system operates.

DIAGNOSTIC PROCEDURE

Diagnostic Table 2 (Cont'd)

INSPECTION ITEM		E C C S SYSTEM INSPECTION																										
		THROTTLE VALVE SWITCH		EGR CONTROL SOLENOID VALVE		EXHAUST GAS SENSOR		INJECTOR	NEUTRAL SWITCH		STARTER SIGNAL		IGNITION SIGNAL		BATTERY VOLTAGE		FUEL PUMP CIRCUIT			A I V CONTROL SOLENOID VALVE		FUEL TEMP SENSOR		P R CONTROL SOLENOID VALVE		VEHICLE SPEED SENSOR		
		Short	Open	Short	Open	Short	Open	Clog ging	Short	Open	Short	Open	Short	Open	Low	High	Short	Open	Short	Open	Short	Open	Short	Open	Short	Open	Short	Open
TROUBLE ITEMS CONCERNED WITH DRIVEABILITY	EF & EC 70			EF & EC-82		EF & EC 74		-	EF & EC-88		EF & EC 68		EF & EC-60		EF & EC 62		EF & EC 80		EF & EC-66		EF & EC 90		EF & EC 72					
	Heavy load	○		⊗		○		⊗								○												
	Middle load	○		⊗		○		⊗								○												
SURGE	Light load	○		⊗		○		⊗								○												
	Slow acceleration	○		⊗		○		⊗								○												
	Rapid deceleration			○		○		⊗								○												
	Slow deceleration			○		○		⊗								○												
	Rapid acceleration	○		○		○		⊗								○												
	Slow acceleration	○		○		○		⊗								○												
	Rapid acceleration	○		○		○		⊗								○												
	Slow acceleration	○		○		○		⊗								○												
BACKFIRE		○				○		⊗								○												
AFTER FIRE				○				⊗																				
IDLE STABILITY				○				⊗																				
ENGINE STALL				○				⊗																				
STARTABILITY				○				⊗																				

SELF-DIAGNOSIS



Description

The self-diagnosis is useful to diagnose malfunctions in major sensors and actuators of the E C C S system. There are 5 modes in the self-diagnosis system

1. Mode I – Mixture ratio feedback control monitor A

- During closed loop condition

The green inspection lamp turns ON when lean condition is detected and goes OFF by rich condition

With clamping, mixture conditions (lean or rich) just before clamping are maintained

- During open loop condition

The green inspection lamp keeps OFF

2. Mode II – Mixture ratio feedback control monitor B

The green inspection lamp function is the same as Mode I.

- During closed loop condition

The red inspection lamp turns ON and OFF simultaneously with the green inspection lamp when the mixture ratio is controlled within the specified value

- During open loop condition

The red inspection lamp stays OFF.

3. Mode III – Self-diagnosis

This mode is the same as the former self-diagnosis in self-diagnosis mode

4. Mode IV – Switches ON/OFF diagnosis


During this mode, the inspection lamps monitor the switch ON-OFF condition

- Throttle valve switch
- Starter switch
- Vehicle speed sensor

5. Mode V – Real time diagnosis

The moment the malfunction is detected, the display will be presented immediately. That is, the condition at which the malfunction occurs can be found by observing the inspection lamps during driving test.


SELF-DIAGNOSIS



SEF872D

Description (Cont'd) SWITCHING THE MODES

- 1 Turn ignition switch "ON".
- 2 Turn diagnostic mode selector on E.C.U. fully clockwise and wait the inspection lamps flash
- 3 Count the number of the flashing time, and after the inspection lamps have flashed the number of the required mode, turn diagnostic mode selector fully counterclockwise immediately



SEF989D

When the ignition switch is turned off during diagnosis, in each mode, and then turned back on again after the power to the E.C.U. has dropped off completely, the diagnosis will automatically return to Mode I.

The stored memory would be lost if

- 1 Battery terminal is disconnected
 - 2 After selecting Mode III, Mode IV is selected
- However, if the diagnostic mode selector is kept turned fully clockwise, it will continue to change in the order of Mode I → II → III → IV → V → I etc., and in this state the stored memory will not be erased

SELF-DIAGNOSIS

Modes I & II — Mixture Ratio Feedback Control Monitors A & B

In these modes, the control unit provides the Air-fuel ratio monitor presentation and the Air-fuel ratio feedback coefficient monitor presentation

Mode	LED	Engine stopped	Engine running			
			Open loop condition	Closed loop condition		
Mode I (Monitor A)	Green	ON	OFF	<ul style="list-style-type: none"> ● OFF rich condition ● ON lean condition ● Maintains conditions just before clamping 		
	Red	ON	OFF	OFF		
Mode II (Monitor B)	Green	ON	OFF	<ul style="list-style-type: none"> ● OFF rich condition ● ON lean condition ● Maintains conditions just before clamping 		
	Red	OFF	OFF	Compensating mixture ratio		
				More than 5% rich	Between 5% lean and 5% rich	More than 5% lean
			OFF	Synchronized with green LED	ON	

SELF-DIAGNOSIS

Mode III — Self-diagnostic System

The E C U constantly monitors the function of these sensors and actuators, regardless of ignition key position. If a malfunction occurs, the information is stored in the E C U and can be retrieved from the memory by turning on the diagnostic mode selector, located on the side of the E C U. When activated, the malfunction is indicated by flashing a red and a green L E D (Light Emitting Diode), also located on the E C U. Since all the self-diagnostic results are stored in the E C U's memory even intermittent malfunctions can be diagnosed.

A malfunctioning part's group is indicated by the number of both the red and the green L E D s flashing. First, the red L E D flashes and the green flashes follow. The red L E D refers to the number of tens while the green one refers to the number of units. For example, when the red L E D flashes once and then the green one flashes twice, this means the number "12" showing the air flow meter signal is malfunctioning. In this way, all the problems are classified by the code numbers.

- When engine fails to start, crank engine more than two seconds before starting self-diagnosis
- Before starting self-diagnosis, do not erase stored memory. If doing so, self-diagnosis function for intermittent malfunctions would be lost.

The stored memory would be lost if

- 1 Battery terminal is disconnected
- 2 After selecting Mode III, Mode IV is selected.

DISPLAY CODE TABLE

Code No	Detected items
11	Crank angle sensor circuit
12	Air flow meter circuit
13	Cylinder head temperature sensor circuit
21	Ignition signal missing in primary coil
22	Fuel pump circuit
34	Detonation sensor circuit [VG30ET]
41	Fuel temperature sensor circuit
44	No malfunctioning in the above circuits


SELF-DIAGNOSIS

Mode III — Self-Diagnostic System (Cont'd)

RETENTION OF DIAGNOSTIC RESULTS

The diagnostic result is retained in E.C.U. memory until the starter is operated fifty times after a diagnostic item is judged to be malfunctioning. The diagnostic result will then be cancelled automatically. If a diagnostic item which has been judged to be malfunctioning and stored in memory is again judged to be malfunctioning before the starter is operated fifty times, the second result will replace the previous one. It will be stored in E.C.U. memory until the starter is operated fifty times more.

RETENTION TERM CHART (Example)



If the same diagnostic item is judged to be malfunctioning before the starter is operated fifty times, it will be stored in E.C.U. memory until the starter is operated fifty times from this point in time.



Retention term




Malfunction detecting point

SEF793D

SELF-DIAGNOSIS

Mode III — Self-diagnostic System (Cont'd) SELF-DIAGNOSTIC PROCEDURE



CAUTION

During displaying code No in self-diagnosis mode (mode III), if the other diagnostic mode should be done, make sure to write down the malfunctioning code No before turning diagnostic mode selector on ECU fully clockwise, or select the diagnostic mode after turning switch "OFF". Otherwise self-diagnosis information stored in E.C.U memory until now would be lost.

SELF-DIAGNOSIS



Mode III — Self-diagnostic System (Cont'd) DECODING CHART

Display code

Malfunctioning circuit or parts

Control unit shows a malfunction signal when the following conditions are detected.

CRANK ANGLE SENSOR





- Either 1° or 120° signal is not entered for the first few seconds during engine cranking
- Either 1° or 120° signal is not input often enough while the engine speed is higher than the specified rpm

SYSTEM INSPECTION
See page EF & EC-54

SEF990D

AIR FLOW METER





- The air flow meter circuit is open or shorted (An abnormally high or low voltage is entered)

SYSTEM INSPECTION
See page EF & EC-56

SEF280E

CYLINDER HEAD TEMPERATURE SENSOR





- The cylinder head temperature sensor circuit is open or shorted (An abnormally high or low output voltage is entered)

SYSTEM INSPECTION
See page EF & EC-58

SEF833C

IGNITION SIGNAL



- The ignition signal in primary circuit is not entered during engine cranking or running

SYSTEM INSPECTION
See page EF & EC-60

SEF993D

SELF-DIAGNOSIS




Mode III — Self-diagnostic System (Cont'd)

Display code

Malfunctioning circuit or parts




Control unit shows a malfunction signal when the following conditions are detected

FUEL PUMP CONTROL






SEF994D

DETONATION SENSOR [VG30ET]





SEF191F

FUEL TEMPERATURE SENSOR



SEF281E



SEF841C

Mode IV — Switches ON/OFF Diagnostic System

In switches ON/OFF diagnosis system, ON/OFF operation of the following switches can be detected continuously

- Throttle valve switch
- Starter switch
- Vehicle speed sensor

(1) Throttle valve switch & Starter switch

The switches ON/OFF status at the point when mode IV is selected is stored in E C U memory. When either switch is turned from "ON" to "OFF" or "OFF" to "ON", the red L.E.D on E C U alternately comes on and goes off each time switching is detected.


(2) Vehicle Speed Sensor

The switches ON/OFF status at the point when mode IV is selected is stored in E C U memory. When vehicle speed is 20 km/h (12 MPH) or slower, the green L E D on E C U is off. When vehicle speed exceeds 20 km/h (12 MPH), the green L.E D on E C U comes "ON".

SELF-DIAGNOSIS

Mode IV — Switches ON/OFF Diagnostic System (Cont'd)

SELF-DIAGNOSTIC PROCEDURE



CAUTION:

- For safety, do not drive rear wheels at higher speed than required.

SELF-DIAGNOSIS


Mode V — Real Time Diagnostic System

In real time diagnosis, if any of the following items are judged to be faulty, a malfunction is indicated immediately

- Crank angle sensor (120° signal & 1° signal)
- Ignition signal
- Air flow meter output signal
- Fuel pump

Consequently, this diagnosis is a very effective measure to diagnose whether the above systems cause the malfunction or not, during driving test. Compared with self-diagnosis, real time diagnosis is very sensitive, and can detect malfunctioning conditions in a moment. Further, items regarded to be malfunctions in this diagnosis are not stored in E C U memory.

SELF-DIAGNOSTIC PROCEDURE



CAUTION

In real time diagnosis, pay attention to inspection lamp flashing. E C U displays the malfunction code only once, and does not memorize the inspection

SELF-DIAGNOSIS

Mode V — Real Time Diagnostic System (Cont'd)

DECODING CHART



Display presentation

Malfunction circuit or parts

Control unit shows a malfunction signal when the following conditions are detected

(Compare with Self Diagnosis — Mode III.)



CRANK ANGLE SENSOR



The 1° or 120° signal is momentarily missing, or, multiple, momentary noise signals enter

REAL TIME DIAGNOSTIC INSPECTION
See page EF & EC-48



AIR FLOW METER



Abnormal, momentary increase in air flow meter output signal

REAL TIME DIAGNOSTIC INSPECTION
See page EF & EC-49


IGNITION SIGNAL



Signal from the primary ignition coil momentarily drops off

REAL TIME DIAGNOSTIC INSPECTION
See page EF & EC-50

FUEL PUMP



Fuel pump circuit is momentarily open or shorted

REAL TIME DIAGNOSTIC INSPECTION
See page EF & EC-51


SELF-DIAGNOSIS

Mode V — Real Time Diagnostic System (Cont'd)

REAL TIME DIAGNOSTIC INSPECTION

Crank Angle Sensor

Check sequence	Check items	Check conditions	Check parts			If malfunction, perform the following items
			Crank angle sensor harness connector	Sensor & actuator	ECU 20- & 16-pin connector	
1	Tap and wiggle harness connector or component during real time diagnosis	During real time diagnosis	○	○	○	Go to check item 2
2	Check harness continuity at connector	Engine stopped	○	X	X	Go to check item 3
3	Disconnect harness connector, and then check dust adhesion to harness connector	Engine stopped	○	X	○	Clean terminal surface
4	Check pin terminal bend	Engine stopped	X	X	○	Take out bend
5	Reconnect harness connector and then recheck harness continuity at connector	Engine stopped	○	X	X	Replace terminal
6	Tap and wiggle harness connector or component during real time diagnosis	During real time diagnosis	○	○	○	If malfunction codes are displayed during real time diagnosis, replace terminal




SELF-DIAGNOSIS

Mode V — Real Time Diagnostic System (Cont'd)

Air Flow Meter

Check sequence	Check items	Check conditions	Check parts			If malfunction, perform the following items
			Air flow meter harness connector	Sensor & actuator	ECU 20- & 16-pin connector	
1	Tap and wiggle harness connector or component during real time diagnosis	During real time diagnosis	○	○	○	Go to check item 2
2	Check harness continuity at connector	Engine stopped	○	X	X	Go to check item 3
3	Disconnect harness connector, and then check dust adhesion to harness connector	Engine stopped	○	X	○	Clean terminal surface
4	Check pin terminal bend	Engine stopped	X	X	○	Take out bend
5	Reconnect harness connector and then recheck harness continuity at connector	Engine stopped	○	X	X	Replace terminal
6	Tap and wiggle harness connector or component during real time diagnosis	During real time diagnosis	○	○	○	If malfunction codes are displayed during real time diagnosis, replace terminal




SEF194F

SELF-DIAGNOSIS

Mode V — Real Time Diagnostic System (Cont'd)

Ignition Signal

Check sequence	Check items	Check conditions	Check parts			If malfunction, perform the following items
			Ignition signal harness connector	Sensor & actuator	ECU 20- & 16-pin connector	
1	Tap and wiggle harness connector or component during real time diagnosis	During real time diagnosis	○	○	○	Go to check item 2
2	Check harness continuity at connector	Engine stopped	○	X	X	Go to check item 3
3	Disconnect harness connector, and then check dust adhesion to harness connector	Engine stopped	○	X	○	Clean terminal surface
4	Check pin terminal bend	Engine stopped	X	X	○	Take out bend
5	Reconnect harness connector and then recheck harness continuity at connector	Engine stopped	○	X	X	Replace terminal
6	Tap and wiggle harness connector or component during real time diagnosis	During real time diagnosis	○	○	○	If malfunction codes are displayed during real time diagnosis, replace terminal




SEF195F

SELF-DIAGNOSIS






Mode V — Real Time Diagnostic System (Cont'd)

Fuel pump

Check sequence	Check items	Check conditions	Check parts			If malfunction, perform the following items
			Fuel pump harness connector	Sensor & actuator	ECU 20- & 16-pin connector	
1	Tap and wiggle harness connector or component during real time diagnosis	During real time diagnosis	○	○	○	Go to check item 2
2	Check harness continuity at connector	Engine stopped	○	X	X	Go to check item 3
3	Disconnect harness connector, and then check dust adhesion to harness connector	Engine stopped	○	X	○	Clean terminal surface
4	Check pin terminal bend	Engine stopped	X	X	○	Take out bend
5	Reconnect harness connector and then recheck harness continuity at connector	Engine stopped	○	X	X	Replace terminal
6	Tap and wiggle harness connector or component during real time diagnosis	During real time diagnosis	○	○	○	If malfunction codes are displayed during real time diagnosis, replace terminal




ELECTRONIC CONTROL SYSTEM INSPECTION



CAUTION:

1. Before connecting or disconnecting E C U. harness connector to or from any E.C.U., be sure to turn the ignition switch to the "OFF" position and disconnect the negative battery terminal in order not to damage E.C.U. as battery voltage is applied to E.C.U. even if ignition switch is turned off. Otherwise, there may be damage to the E.C.U.
2. When performing E.C.U input/output signal inspection, remove pin terminal retainer from 20- and 16-pin connector to make it easier to insert tester probe into connector.
3. When connecting pin connectors into E C.U. or disconnecting them from E.C.U., take care not to damage pin terminal of E C.U. (Bend or break).
4. Make sure that there are not any bends or breaks on E.C.U. pin terminal, when connecting pin connectors into E.C.U.
5. Before replacing E.C.U., perform E.C.U. input/output signal inspection and make sure whether E.C U functions properly or not. (See page EF & EC-94.)
6. After performing this "ELECTRONIC CONTROL SYSTEM INSPECTION", perform E.C.C.S self-diagnosis and driving test.

ELECTRONIC CONTROL SYSTEM INSPECTION



7. When measuring supply voltage of E.C.U. controlled components with a circuit tester, separate one tester probe from the other.

If the two tester probes accidentally make contact with each other during measurement, the circuit will be shorted, resulting in damage to the power transistor of the control unit.

8. Keys to symbols

DISCONNECT



: Check after disconnecting the connector to be measured

CONNECT



: Check after connecting the connector to be measured.

9. When measuring voltage or resistance at connector with tester probes, there are two methods of measurement; one is done from terminal side and the other from harness side. Before measuring, confirm symbol mark again.



: Inspection should be done from harness side.




: Inspection should be done from terminal side

Refer to G1 section.




10. As for continuity check of joint connector, refer to EL section.

ELECTRONIC CONTROL SYSTEM INSPECTION

CRANK ANGLE SENSOR (Code No. 11)







SEF197F




ELECTRONIC CONTROL SYSTEM INSPECTION

CRANK ANGLE SENSOR (Code No. 11)






ELECTRONIC CONTROL SYSTEM INSPECTION

AIR FLOW METER (Code No. 12)






SEF198F





ELECTRONIC CONTROL SYSTEM INSPECTION

AIR FLOW METER (Code No. 12)







ELECTRONIC CONTROL SYSTEM INSPECTION

CYLINDER HEAD TEMPERATURE SENSOR (Code No. 13)




ELECTRONIC CONTROL SYSTEM INSPECTION

CYLINDER HEAD TEMPERATURE SENSOR (Code No. 13)






ELECTRONIC CONTROL SYSTEM INSPECTION

IGNITION SIGNAL (Code No. 21)








SEF200F




ELECTRONIC CONTROL SYSTEM INSPECTION

IGNITION SIGNAL (Code No. 21)





ELECTRONIC CONTROL SYSTEM INSPECTION

FUEL PUMP (Code No. 22)




SEF201F



ELECTRONIC CONTROL SYSTEM INSPECTION

FUEL PUMP (Code No. 22)



INSPECTION START

A

CHECK POWER SOURCE

- 1) Disconnect fuel pump harness connector
- 2) Turn ignition switch "ON"
- 3) Check voltage between terminal ① and ground

Voltage Battery voltage

Check the following items

- 1) Harness continuity between battery and fuel pump
- 2) Fuse
- 3) "BR" fusible link
- 4) Ignition switch

B 4) Safety relay

12V direct current is applied between terminals ① and ②		Continuity between terminals ② and ③
①	②	
-	+	Yes
+	-	No


C

CHECK GROUND CIRCUIT

- 1) Turn ignition switch "OFF"
- 2) Disconnect ECU 15-pin connector
- 3) Check resistance between ECU terminals ①08 and ①C

Resistance Approximately 0Ω

Repair harness



D

CHECK OUTPUT SIGNAL

- 1) Reconnect ECU 15-pin connector and fuel pump harness connector
- 2) Turn ignition switch "ON"
- 3) Check voltage between ECU terminal ①08 and ground


- i) Water temperature is below 60°C (140°F).
The indicator should read 0V, for 5 seconds after turning ignition switch "ON".
- ii) Water temperature is above 60°C (140°F).
The indicator should read 0V, for 4 minutes after turning ignition switch "ON".

E 1) Check fuel pump

- Disconnect fuel pump harness connector
- Check resistance between terminals ① and ①C

Continuity should exist.
If N G, replace fuel pump

F 2) Fuel pump relay
(Refer to EL section)




Erase the self-diagnosis memory

Perform driving test and then perform self-diagnosis again (Mode-III)

1) Perform ECU input/output signal inspection test


2) If N G, recheck the ECU pin terminals damage or the connection of ECU harness connector



INSPECTION END




ELECTRONIC CONTROL SYSTEM INSPECTION

DETONATION SENSOR (Code No. 34)




ELECTRONIC CONTROL SYSTEM INSPECTION

DETONATION SENSOR (Code No. 34)



ELECTRONIC CONTROL SYSTEM INSPECTION




FUEL TEMPERATURE SENSOR (Code No. 41)



SEF203F


ELECTRONIC CONTROL SYSTEM INSPECTION

FUEL TEMPERATURE SENSOR (Code No. 41)



ELECTRONIC CONTROL SYSTEM INSPECTION



START SIGNAL (Switch ON/OFF diagnosis)



SEF204F


ELECTRONIC CONTROL SYSTEM INSPECTION

START SIGNAL (Switch ON/OFF diagnosis)



ELECTRONIC CONTROL SYSTEM INSPECTION




THROTTLE VALVE SWITCH (Switch ON/OFF diagnosis)



SEF205F


ELECTRONIC CONTROL SYSTEM INSPECTION

THROTTLE VALVE SWITCH (Switch ON/OFF diagnosis)



ELECTRONIC CONTROL SYSTEM INSPECTION




VEHICLE SPEED SENSOR (Switch ON/OFF diagnosis)



SEF206F


ELECTRONIC CONTROL SYSTEM INSPECTION

VEHICLE SPEED SENSOR (Switch ON/OFF diagnosis)



ELECTRONIC CONTROL SYSTEM INSPECTION





EXHAUST GAS SENSOR (Not self-diagnostic item)



SEF207F


ELECTRONIC CONTROL SYSTEM INSPECTION

EXHAUST GAS SENSOR (Not self-diagnostic item)




ELECTRONIC CONTROL SYSTEM INSPECTION

INJECTOR (Not self-diagnostic item)




SEF208F



SEF238F

ELECTRONIC CONTROL SYSTEM INSPECTION


POWER SOURCE & GROUND CIRCUIT FOR E.C.U. (Not self-diagnostic item)




SEF209F

ELECTRONIC CONTROL SYSTEM INSPECTION


POWER SOURCE & GROUND CIRCUIT FOR E.C.U. (Not self-diagnostic item)




SEF153D



SEF167E




SEF168E







ELECTRONIC CONTROL SYSTEM INSPECTION

A.I.V. CONTROL SOLENOID VALVE (Not self-diagnostic item)




ELECTRONIC CONTROL SYSTEM INSPECTION

A.I.V. CONTROL SOLENOID VALVE (Not self-diagnostic item)







ELECTRONIC CONTROL SYSTEM INSPECTION

E.G.R. CONTROL SOLENOID VALVE (Not self-diagnostic item)




ELECTRONIC CONTROL SYSTEM INSPECTION

E.G.R. CONTROL SOLENOID VALVE (Not self-diagnostic item)







ELECTRONIC CONTROL SYSTEM INSPECTION

IDLE-UP SOLENOID VALVE (Not self-diagnostic item)




ELECTRONIC CONTROL SYSTEM INSPECTION

IDLE-UP SOLENOID VALVE (Not self-diagnostic item)



ELECTRONIC CONTROL SYSTEM INSPECTION






A.A.C. VALVE (Not self-diagnostic item)



SEF241F


ELECTRONIC CONTROL SYSTEM INSPECTION

A.A.C. VALVE (Not self-diagnostic item)






ELECTRONIC CONTROL SYSTEM INSPECTION

NEUTRAL/INHIBITOR SWITCH (Not self-diagnostic item)




ELECTRONIC CONTROL SYSTEM INSPECTION

NEUTRAL/INHIBITOR SWITCH (Not self-diagnostic item)







ELECTRONIC CONTROL SYSTEM INSPECTION

P.R. CONTROL SOLENOID VALVE (Not self-diagnostic item)




ELECTRONIC CONTROL SYSTEM INSPECTION

P.R. CONTROL SOLENOID VALVE (Not self-diagnostic item)



ELECTRONIC CONTROL SYSTEM INSPECTION





AIR REGULATOR (Not self-diagnostic item)




SEF215F

ELECTRONIC CONTROL SYSTEM INSPECTION

AIR REGULATOR (Not self-diagnostic item)




E.C.U. INPUT/OUTPUT SIGNAL INSPECTION




MEASUREMENT VOLTAGE OR RESISTANCE OF E C.U.


- 1 Disconnect battery ground cable
- 2 Disconnect 20- and 16-pin connectors from E C U



- 3 Remove pin terminal retainer from 20- and 16-pin connectors to make it easier to insert tester probes



- 4 Connect 20- and 16-pin connectors to E C U carefully
- 5 Connect battery ground cable.
- 6 Measure the voltage at each terminal by following "E C U inspection table"



CAUTION.

- a. Perform all voltage measurements with the connectors connected
- b. Perform all resistance measurements with the connectors disconnected
- c. Make sure that there is not any bend or break on E.C.U. pin terminal before measurements.
- d. Do not touch tester probes between terminals ⑳ and ㉘, ㉝ and ㉞.

E.C.U. INPUT/OUTPUT SIGNAL INSPECTION

E.C.U. inspection table

*Data are reference values

TERMI- NAL NO	ITEM	CONDITION	*DATA
2	Idle-up solenoid valve [VG30E]	Engine is running and gear position is in P or N (A/T)	0.1 - 0.4V
		<ul style="list-style-type: none"> └ For about 20 seconds after starting engine └ When turning steering wheel └ Heater or air conditioner switch is "ON" └ Lighting switch position is "ON" 	
	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running</div> <ul style="list-style-type: none"> └ Except the conditions shown above 	BATTERY VOLTAGE (11 - 14V)	
	A A C valve [VG30ET]	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running</div> <ul style="list-style-type: none"> └ At idle (After warming up) 	6.0 - 8.0V
3	Ignition signal	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
4	E G R control solenoid valve	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running after being warmed up</div> <ul style="list-style-type: none"> └ High engine revolution └ Idle speed (Throttle valve switch "ON") 	Approximately 1.0V
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running</div> <ul style="list-style-type: none"> └ Low engine revolution 	BATTERY VOLTAGE (11 - 14V)
5	Ignition signal (from power transistor)	Engine is running. Do not turn engine at high speed under no-load	0.5 - 2.0V
6	Main relay	Ignition switch "ON"	0.7 - 0.9V
8	Crank angle sensor (position signal)	At idle	2.0 - 3.0V
9	Start signal	Cranking	BATTERY VOLTAGE (11 - 14V)

E.C.U. INPUT/OUTPUT SIGNAL INSPECTION

*Data are reference values.

TERMI- NAL NO	ITEM	CONDITION	*DATA
10	Neutral switch (M/T) Inhibitor switch (A/T) [VG30ET]	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> ↳ Gear position is in Neutral or Parking	0V
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> ↳ Any gear position except Neutral or Parking	4.0 - 5.0V
12	Air flow meter (Self-cleaning signal)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Race engine at more than 1,500 rpm and then turn ignition switch "OFF"</div> ↳ For 6 seconds	0V
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Race engine at more than 1,500 rpm and then turn ignition switch "OFF"</div> ↳ For one second after 6 seconds	9.0 - 10.0V
14	A I V control solenoid valve	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> ↳ Release accelerator pedal (Throttle valve switch "ON")	0.7 - 0.9V
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> ↳ Depress accelerator pedal (Throttle valve switch "OFF")	BATTERY VOLTAGE (11 - 14V)
15	Fuel temperature sensor	At idle	0 - 5V Output voltage varies with engine temperature
16	Air regulator	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> ↳ For 5 seconds after turning ignition switch "ON"	0.1 - 0.3V
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> ↳ After 5 seconds with ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
17	Crank angle sensor (Reference signal)	Engine is running. Do not turn engine at high speed under no-load	0.2 - 0.4V

E.C.U. INPUT/OUTPUT SIGNAL INSPECTION

*Data are reference values

TERMI- NAL NO	ITEM	CONDITION	*DATA
18	Throttle valve switch (⊖ side)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └ Release accelerator pedal (Throttle valve switch "OFF")	9.0 - 10.0V
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └ Depress accelerator pedal (Throttle valve switch "ON")	0V
19	Pressure regulator control solenoid valve	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Stop and restart engine after warming it up</div> └ For 30 seconds	0.8 - 1.0V
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Stop and restart engine after warming it up</div> └ After 3 minutes	BATTERY VOLTAGE (11 - 14V)
20	Fuel pump relay	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └ For 5 seconds after turning ignition switch "ON"	0.1 - 0.3V
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └ After 5 seconds with ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
22	Load signal	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running and gear position is in P or N (A/T)</div> └ When turning steering wheel └ Air conditioner switch is "ON" └ Rear defogger switch is "ON" └ Lighting switch position is "ON"	BATTERY VOLTAGE (11 - 14V)
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running</div> └ Except the conditions shown above	0V
23	Cylinder head temperature sensor	Engine is running	0 - 5.0V Output voltage varies with engine temperature
24	Exhaust gas sensor	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running</div> └ After warming up sufficiently	0 - Approximately 1.0V
25	Throttle valve switch (⊕ side)	Ignition switch "ON"	9.0 - 10.0V


E.C.U. INPUT/OUTPUT SIGNAL INSPECTION

*Data are reference values.


TERMI- NAL NO	ITEM	CONDITION	*DATA
27 35	Power source for E C U	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
29	Vehicle speed sensor	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └ While rotating rear wheel slowly	0 or 7 4V
30	Air flow meter	Ignition switch "ON"	2 0 - 4 0V
31	Air quantity signal	Race engine from idle to 3,000 rpm	2 0 - 4 0V
34	Ignition switch signal	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
101 102 103 104 105 106 114	Injector	Ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
108	Fuel pump	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └ For 5 seconds after turning ignition switch "ON"	0 1 - 0 3V
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └ After 5 seconds with ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
115	Exhaust gas sensor heater	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)

VG30 PIN CONNECTOR TERMINAL LAYOUT

15-pin connector



20-pin connector



16-pin connector



SEF262F

MIXTURE RATIO FEEDBACK SYSTEM INSPECTION

PREPARATION

1. Make sure that the following parts are in good order.

- Battery
- Ignition system
- Engine oil and coolant levels
- Fuses
- E.C.C.S. harness connectors
- Vacuum hoses
- Air intake system
(oil filler cap, oil level gauge, etc.)
- Fuel pressure
- A.I.V. hose
- Engine compression
- E.G R. valve operation
- Throttle valve

2. On air conditioner equipped models, checks should be carried out while the air conditioner is "OFF".

3. On automatic transmission equipped models, when checking idle rpm, ignition timing and mixture ratio, checks should be carried out while shift lever is in "D" position.

4. When measuring "CO" percentage, insert probe more than 40 cm (15.7 in) into tail pipe.


WARNING:

a. When selector lever is shifted to "D" position, apply parking brake and block both front and rear wheels with chocks.

b. Depress brake pedal while racing the engine to prevent forward surge of vehicle.

c. After the adjustment has been made, shift the lever to the "N" or "P" position and remove wheel chocks.

Overall inspection sequence




MIXTURE RATIO FEEDBACK SYSTEM INSPECTION

Idle Check and Set Procedure

INSPECTION START

- Visually check the following
- Air cleaner clogging
 - Hoses and ducts for leaks
 - E G R valve operation
 - Electrical connectors
 - Gaskets
 - Throttle valve switch operation
 - A I V hose



SEF246F

Start engine and warm up until water temperature indicator points to the middle of gauge



SEF247F

Run engine at about 2,000 rpm for about 2 minutes under no-load

Perform E C C S self-diagnosis

OK

NG


Repair or replace components as necessary

Does engine run smoothly?

Yes

No


Clean injectors



SEF644B

VG30E only
Stop engine and disconnect idle-up solenoid valve harness connector Start engine

Race engine two or three times under no-load and run engine for about one minute at idle speed



SEF248F

Check ignition timing

VG30E- $20^{\circ} \pm 2^{\circ}$ B.T.D.C.

VG30ET $15^{\circ} \pm 2^{\circ}$ B.T.D.C.

OK


NG

Adjust ignition timing by turning distributor after loosening bolt which secures distributor


(A)

(B)

MIXTURE RATIO FEEDBACK SYSTEM INSPECTION



MIXTURE RATIO FEEDBACK SYSTEM INSPECTION




Check whether green and red inspection lamps on E C U flash simultaneously

OK NG

Connect throttle valve switch harness connector

INSPECTION END





Check exhaust gas sensor harness

- 1) Turn off engine and disconnect battery ground cable
- 2) Disconnect 16-pin connector from E C U
- 3) Disconnect exhaust gas sensor harness connector and connect main harness side terminal for exhaust gas sensor to ground with a jumper wire
- 4) Check for continuity between terminal No 24 of 16-pin connector and body ground

Continuity exists OK
Continuity does not exist NG


Repair or replace harness

Connect 16-pin connector to E C U




- Disconnect cylinder head temperature sensor harness connector
- Connect a resistor (2.5 kΩ) between terminals of cylinder head temperature sensor harness connector


Connect battery ground cable, start engine and warm it up until water temperature indicator points to middle of gauge




Race engine two or three times under no-load, then run engine at idle




MIXTURE RATIO FEEDBACK SYSTEM INSPECTION



MIXTURE RATIO FEEDBACK SYSTEM INSPECTION



FUEL SYSTEM INSPECTION



Releasing Fuel Pressure

WARNING

Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.


1. Remove fuse for fuel pump.

2. Start engine

3. After engine stalls, crank engine two or three times to make sure that pressure is released

4. Turn ignition switch off and install the fuse

Erase the memory (Code No. 22) of the self-diagnosis in E.C.C.S. control unit



Fuel Pressure Check

a. When reconnecting fuel line, always use a new clamp.

b. Tighten the clamp so its end is 3 mm (0.12 in) from the hose end.

c. Make sure that the screw of the clamp does not contact with any adjacent parts.



 : Fuel hose clamps

1.0 - 1.5 N·m

(0.10 - 0.15 kg-m, 0.7 - 1.1 ft-lb)

d. Disconnect pressure regulator control solenoid valve harness connector.

e. Use Pressure Gauge to check fuel pressure.



1. Release fuel pressure to zero

2. Disconnect fuel hose between fuel filter and fuel tube (engine side).

3. Install pressure gauge between fuel filter and fuel tube

FUEL SYSTEM INSPECTION

Fuel Pressure Check (Cont'd)

4. Start engine and check for fuel leakage.
5. Read the indication of fuel pressure gauge

At idling:

Approximately 206 kPa
(2.1 kg/cm², 30 psi)

The moment accelerator pedal is fully depressed:


[VG30E]

Approximately 255 kPa
(2.6 kg/cm², 37 psi)


[VG30ET]

Approximately 304 kPa
(3.1 kg/cm², 44 psi)

6. Stop engine and disconnect fuel pressure regulator vacuum hose from intake collector
7. Plug intake collector with a rubber cap
8. Connect variable vacuum source to fuel pressure regulator



9. Jump No. 108 connector of E C U. to body ground.







10. Turn ignition switch to "ON" and read the indication of fuel pressure gauge as vacuum is changed

Vacuum kPa (mmHg, inHg)	Fuel pressure kPa (kg/cm ² , psi)
0 (0, 0)	248.1 - 255.0 (2.53 - 2.60, 36.0 - 37.0)
16.9 (127, 5.00)	227.5 - 241.3 (2.32 - 2.46, 33.0 - 35.0)
33.9 (254, 10.00)	213.8 - 220.7 (2.18 - 2.25, 31.0 - 32.0)
50.8 (381, 15.00)	200.1 - 206.9 (2.04 - 2.11, 29.0 - 30.0)
67.7 (508, 20.00)	179.5 - 193.2 (1.83 - 1.97, 26.0 - 28.0)

- Fuel pressure should decrease as vacuum increases. If results are unsatisfactory, replace fuel pressure regulator.

FUEL SYSTEM INSPECTION




Injector Removal and Installation

- 1 Release fuel pressure to zero
- 2 Disconnect the following from intake collector
 - Air duct
 - Accelerator wire
 - Blow-by hoses
 - Air regulator hose
 - E G R. tube
 - Harness clamps
 - Harness connectors
 - Intake collector cover
 - Water hoses
- 3 Disconnect fuel hoses
- 4 Remove intake collector.
5. Remove bolts securing fuel tube
- 6 Remove bolts securing injectors and remove injectors, fuel tubes and pressure regulator as an assembly.
7. Remove fuel hose
 - 1) Heat sharp knife for 15 minutes. Cut into hose braided reinforcement from mark to socket end and fuel tube end
Do not allow sharp knife to cut all the way through the hose and touch injector tail piece.
 - 2) Then pull rubber hose out with hand.
Never place injector in a vise when disconnecting rubber hose.
8. Install fuel hose as follows
 - 1) Clean exterior of injector tail piece and fuel tube end.
 - 2) Wet inside of new rubber hose with fuel.
 - 3) Push end of rubber hose with hose sockets onto injector tail piece and fuel tube end by hand as far as they will go
Clamp is not necessary at the connections.

CAUTION
After properly connecting fuel hose to injector and fuel tube, check connection for fuel leakage

TURBOCHARGER INSPECTION

Disassembly and Assembly



Inspection

Condition 1 Low engine power

Probable cause	Corrective action
Air leak at the connection of compressor housing and suction hose/inlet tube, or inlet tube and intake manifold	Correct the connection
Exhaust gas leak at the connection of turbine housing and exhaust manifold, connecting tube or exhaust outlet	Correct the connection or replace gasket
By-pass valve is stuck open	Replace turbocharger assembly
Stuck or worn journal or bearing	
Broken shaft	
Sludge on back of turbine wheel	
Broken turbine wheel	

TURBOCHARGER INSPECTION


Inspection (Cont'd)

Condition 2 Excessively high engine power

Probable cause	Corrective action
Disconnected or cracked rubber hose on by-pass valve	Replace turbocharger assembly
By-pass valve is stuck closed.	
Controller diaphragm is broken	
	Correct or replace rubber hose

Condition 3 Excessively high oil consumption or exhaust shows pale blue smoke


Probable cause	Corrective action
Oil leak at the connection of lubricating oil passage	Replace turbocharger assembly
Oil leak at oil seal of turbine	
Oil leak at oil seal of compressor	
Worn journal or bearing	
	Correct the connection



- Inspect turbine and compressor wheel as follows:
 - Visually check for cracks, clogging, deformity or other damage.
 - Revolve wheels to make sure that they turn freely without any abnormal noise or friction.
 - Measure play in axial direction.

Play (axial direction):

0.013 - 0.091 mm (0.0005 - 0.0036 in)



- Check operation of by-pass valve controller.
 - Move by-pass valve to make sure that it is not sticking or scratched.
 - Measure rod end play of the by-pass valve controller.

Do not apply more than 66.7 kPa (500 mmHg, 19.69 inHg) pressure to controller diaphragm.


By-pass valve controller stroke/pressure:

0.38 mm (0.0150 in)/51.3 - 56.7 kPa

(385 - 425 mmHg, 15.16 - 16.73 inHg)

EVAPORATIVE EMISSION CONTROL SYSTEM

Description



The evaporative emission control system is used to reduce hydrocarbons emitted to the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the carbon canister.

The fuel vapor from the sealed fuel tank is led into the canister which contains activated carbon and the vapor is stored there when the engine is not running.


The canister retains the fuel vapor until the canister is purged by the air drawn through the bottom of the canister to the intake manifold when the engine is running. When the engine runs at idle, the purge control valve is closed.

Only a small amount of stored vapor flows into the intake manifold through the constant purge orifice. As the engine speed increases, and the throttle vacuum rises higher, the purge control valve opens and the vapor is sucked into the intake manifold through both the main purge orifice and the constant purge orifice.


Inspection CARBON CANISTER

Check carbon canister as follows

- (A) Blow air and ensure that there is no leakage.
- (B) Blow air and ensure that there is leakage.




EVAPORATIVE EMISSION CONTROL SYSTEM



Inspection (Cont'd)

FUEL TANK VACUUM RELIEF VALVE

- 1 Wipe clean valve housing
- 2 Inhale air through the cap. A slight resistance accompanied by valve clicks indicates that valve is in good mechanical condition. Note also that, by further inhaling air, the resistance should be disappeared with valve clicks
- 3 If valve is clogged, or if no resistance is felt, replace cap as an assembly




FUEL CHECK VALVE

- 1 Blow air through connector on fuel tank side. A considerable resistance should be felt and a portion of air flow be directed toward the canister
- 2 Blow air through connector on the canister side. Air flow should be smoothly directed toward fuel tank
- 3 If fuel check valve is suspected of not being properly functioning in steps 1 and 2 above, replace it

VAPOR VENT LINE


- 1 Check hoses and fuel tank filler cap
- 2 Disconnect the vapor vent line connecting carbon canister to fuel tank



- 3 Connect a 3-way connector, a manometer and a cock (or an equivalent 3-way charge cock) to the end of the vent line
- 4 Supply fresh air into the vapor vent line through the cock little by little until pressure becomes 3 923 kPa (400 mmH₂O, 15 75 inH₂O)
- 5 Shut the cock completely and leave it unattended
- 6 After 2 5 minutes, measure the height of the liquid in the manometer
- 7 Variation in height should remain at 0 245 kPa (25 mmH₂O, 0 98 inH₂O)
- 8 When filler cap does not close completely, the height should drop to zero in a short time
- 9 If the height does not drop to zero in a short time when filler cap is removed, the cause is a blocked hose or a clogged fuel check valve

In case the vent line is blocked, the fuel tank is not vented properly causing insufficient deliver of fuel to engine, or vapor lock. It must, therefore, be repaired.


E.G.R. SYSTEM INSPECTION



ENTIRE SYSTEM

Ensure that E G R. system is functioning properly by placing your finger on E G R control valve diaphragm.
Make sure that E.G R control valve operates as follows.


Conditions	E G R control solenoid	E G R system
<ol style="list-style-type: none"> ① Engine starting ② Throttle valve switch "ON" ③ Low engine temperature ④ High engine temperature ⑤ High engine speed ⑥ With heavy load 	ON	Does not operate
Except above	OFF	Operates



E.G.R. CONTROL SOLENOID VALVE

- 1 Check the solenoid valve for electric continuity, after disconnecting the harness connector


Resistance: 30 - 40Ω



2. Check the solenoid valve for normal operation as shown.

CAUTION:

- Be sure to connect ⊕ terminal of battery with white harness of solenoid valve.
- Perform E.G.R. circuit test. (See page EF & EC-82.)
- Perform E.C.U. input/output test. (See page EF & EC-94.)



E.G.R. CONTROL VALVE


1. Supply the E.G.R control valve with vacuum using a handy vacuum pump.
- 2 Place a finger on the diaphragm of the valve, and make sure that the diaphragm lifts up and down in response to the vacuum leading to the valve.

Full open of E.G.R. valve:

Over -16.0 kPa

(-120 mmHg, -4.72 inHg)

CRANKCASE EMISSION CONTROL SYSTEM




Description

The fuel vapor from the sealed fuel tank is led into the canister which contains activated carbon. The vapor is stored there when the engine is not running.

The canister retains the fuel vapor until the canister is purged by the air drawn through the purge line to the intake manifold when the engine is running. When the engine is at idle, the purge control valve is closed.


Only a small amount of purged air flows into the intake manifold through the constant purge orifice. As the engine speed increases, and the throttle vacuum rises higher the purge control valve opens and the vapor is drawn into the intake manifold through both the purge orifice and the constant purge orifice.



Inspection


P.C.V. VALVE

With engine running at idle, remove ventilation hose from P.C.V. valve, if valve is working properly a hissing noise will be heard as air passes through it and a strong vacuum should be felt immediately when a finger is placed over valve inlet.



VENTILATION HOSE

- 1 Check hoses and hose connections for leaks
- 2 Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace




A.I.V. SYSTEM INSPECTION

VISUAL CHECK

Check the hoses and tubes for loosening, flattening damage or faulty connections, and each part for proper installation

- Replace, if necessary




A I.V CONTROL SOLENOID

Subject the solenoid valve to independent inspection, after disconnecting the harness connector and all the vacuum hoses

- 1) Check it for electric continuity

Resistance Approximately 40Ω

- 2) Check the solenoid valve for normal operation Supply it with battery voltage, and check whether there is continuity between ports A, B and C




Solenoid valve		OFF	ON
		Item	ON
Continuity		B-C	A-B

CAUTION

- Be sure to connect ⊕ terminal of battery with white harness of solenoid valve.
- Perform A.I.V. circuit test. (See page EF & EC-80.)
- Perform E.C.U. input/output test. (See page EF & EC-94.)


A.I.V. SYSTEM INSPECTION



A.I.V. UNIT

- 1 Disconnect vacuum hose leading to vacuum motor and set a handy vacuum pump there
- 2 Disconnect hose between A.I.V. unit and air cleaner
- 3 Subject A.I.V. unit to inspection in the following way
Connect suitable hose to A.I.V. unit and try to blow A I V unit through the hose, when vacuum is lead to vacuum motor and when no vacuum exists

	Vacuum	No vacuum	Parts condition
Can you blow?	Yes	No	O K
	No	Yes	N G



- 4 If the inspection shows N G , disassemble the A I V case and check such parts as the reed valve, the vacuum motor, and the connecting hoses

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

General Specifications

Fuel pump	
Cut off discharge pressure kPa (kg/cm ² , psi)	422 - 490 (4 3 - 5 0, 61 - 71)
Pressure regulator	
Regulated pressure kPa (kg/cm ² , psi)	250 (2 55, 36 3)
Air regulator	
Air flow amount [at 20°C (68°F)] m ³ (cu ft)/hr	14 5 (512)

Inspection and Adjustment

Item	
Fuel pressure	
At idle kPa (kg/cm ² , psi)	Approximately 206 (2 1, 30)
The moment accelerator pedal is fully depressed kPa (kg/cm ² , psi)	
VG30E	Approximately 255 (2 6, 37)
VG30ET	Approximately 304 (3 1, 44)
Air flow meter	
Voltage between terminals B and D	2 - 4V
Cylinder head temperature sensor and fuel temperature sensor	
Thermistor resistance at 20°C (68°F)	2 3 - 2 7 kΩ
at 50°C (122°F)	0 77 - 0 87Ω
at 80°C (176°F)	0 30 - 0 33Ω
Throttle valve switch	
Engine speed when idle switch is turned from "OFF" to "ON"	Idle speed + 250 rpm allowance ±150 rpm

Tightening Torque

Unit	N m	kg-m	ft-lb
Throttle chamber securing bolt	18 - 22	1 8 - 2 2	13 - 16
Intake collector cover bolt	6 - 8	0 6 - 0 8	4 3 - 5 8
Intake collector bolt	18 - 22	1 8 - 2 2	13 - 16
Cylinder head temperature sensor	12 - 16	1 2 - 1 6	9 - 12
Exhaust gas sensor (VG30E)	40 - 50	4 1 - 5 1	30 - 37
(VG30ET)	18 - 24	1 8 - 2 4	13 - 17
E G R control valve	18 - 23	1 8 - 2 3	13 - 17
E G R tube	34 - 44	3 5 - 4 5	25 - 33
Fuel hose clamp	1 0 - 1 5	0 10 - 0 15	0 7 - 1 1

NISSAN FACTORY SERVICE MANUAL CDROM END-USER LICENSE AGREEMENT

NOTICE TO USER: THIS IS A CONTRACT. BY PURCHASING AND USING THE SERVICE MANUAL ON CDROM, YOU ACCEPT ALL THE TERMS AND CONDITIONS OF THIS AGREEMENT.

This End User License Agreement accompanies the Service Manual on CDROM product and related explanatory materials. Please read this Agreement carefully. By purchasing and using the Service Manual on CDROM, you are implying that you have carefully read, agree with, and will adhere to the conditions set forth in this agreement. If you do not wish to accept the terms of this End User Agreement please do not use the Service Manual on CDROM. You will not be permitted to use the Service Manual on CDROM without consenting to this end user agreement.

Upon your acceptance of this Agreement, Courtesy Nissan grants to you a nonexclusive license to use the Service Manual on CDROM, provided that you agree to the following:

USE OF SOFTWARE

You may install the contents of the CD on a hard disk or other storage device for personal use only. Each Service Manual on CDROM comes with a single user license. Under no circumstances should the contents of the Service Manual CDROM be placed on a server for purposes of distributing or allowing access to the material over a network.

COPYRIGHT AND TRADEMARK RIGHTS

The Service Manual CDROM is owned by Courtesy Nissan and its structure and organization, all graphics and coding are considered intellectual property of Courtesy Nissan. The Service Manual on CDROM is also protected by United States Copyright Law and International Treaty provisions. This Agreement does not grant you any intellectual property or resale rights to the Service Manual CDROM.

RESTRICTIONS

You agree not to modify, adapt, translate, reverse engineer, decompile or disassemble the PDF file on the Service Manual CDROM. The Service Manual on CDROM is licensed and distributed by Courtesy Nissan for single user utilization of its contents only. Licensed users will be permitted to use the contents of the Service Manual CDROM for multimedia presentation to an audience from a single machine using a large display or projection device but the Service Manual CDROM may not otherwise be distributed, sold to or made accessible to multiple users.

NO WARRANTY

The software is being delivered to you AS IS and Courtesy Nissan makes no warranty as to its use or performance. COURTESY NISSAN DOES NOT AND CANNOT WARRANT THE PERFORMANCE OR RESULTS YOU MAY OBTAIN BY USING THE SERVICE MANUAL CDROM OR DOCUMENTATION, NOR MAKES ANY WARRANTIES, EXPRESS OR IMPLIED, AS TO NONINFRINGEMENT OF THIRD-PARTY RIGHTS, MERCHANTABILITY, OR FITNESS FOR ANY PARTICULAR PURPOSE. IN NO EVENT WILL COURTESY NISSAN BE LIABLE TO YOU FOR ANY CONSEQUENTIAL, INCIDENTAL, OR SPECIAL DAMAGES FOR ANY REASON.

Courtesy Nissan
1777 North Central Expressway
Richardson, TX 75080
(800)527-1909

GOVERNING LAW AND GENERAL PROVISIONS

This Agreement will be governed by the laws of the State of Texas, USA, excluding the application of its conflicts of law rules. This Agreement will not be governed by the United Nations Convention on Contracts for the International Sale of Goods, the application of which is expressly excluded. If any part of this Agreement is found void and unenforceable, it will not affect the validity of the balance of the Agreement, which shall remain valid and enforceable according to its terms. You agree that the Service Manual on CDROM will not be shipped, transferred or exported into any country or used in any manner prohibited by the United States Export Administration act or any other export laws, restrictions or regulations. This Agreement shall automatically terminate upon failure by you to comply with its terms. This Agreement may only be modified in writing signed by and authorized officer for Courtesy Nissan.

Courtesy Nissan
1777 North Central Expressway
Richardson, TX 75080
USA

YOUR ACCEPTANCE OF THE FOREGOING AGREEMENT IS IMPLIED UPON PURCHASING AND USING THE SERVICE MANUAL CDROM.